

POF

USA

CLEANING YOUR WEAPON

Level I
&
Level II

Cleaning LEVEL II



USA

Start with firearm
stripped to Level I.



Field stripping

LEVEL II

USA

Remove the Roller Cam Pin and Bolt from Carrier.



Field stripping

LEVEL II



Depress Buffer Detent to release Buffer and Buffer Spring.



Be sure to control Buffer and Buffer Spring with thumb when clearing Detent.

Field Stripped Ready For Level II Cleaning



Perform

POF

USA

Assemble the Rifle



Perform

FUNCTION TEST

USA

- ▶ Operate charging handle
- ▶ Rotate selector to safe
- ▶ Press trigger
- ▶ Rotate selector to fire/semi
- ▶ Press trigger
- ▶ Hold trigger to rear and operate charging handle
- ▶ Release trigger
- ▶ Rotate selector to auto
- ▶ Press trigger / hold to rear
- ▶ Operate charging handle three times
- ▶ Release trigger

Cleaning

Don't forget, whenever you are cleaning or performing inspections or repairs:

Always inspect and clean all the magazines

